

Ex


Конт	Цель
1	-U
6	-U
3	+U1
7	+U1
4	+U2
8	+U2
5	INF
9	INF

X1

Конт	Цель
1	4-20mA W Out
2	4-20mA W Gnd
3	4-20mA P In
10	4-20mA P Gnd
4	RS485 +U R5K1
5	RS485 I/O
6	RS485 I/O
7	RS485 R110R
8	RS485 R5K1 Gnd
15	RS485 GND

Первичный преобразователь MBH-1.01.03.000

Кабель MBH-1.00.00.000K1



Влагомер MBH-1. Монтажная схема